

**Facoltà di Scienze Matematiche, Fisiche e Naturali**  
**Dipartimento di Scienze dell'Informazione**  
 Corso di Laurea Specialistica in Scienze di Internet (Sdi) e Informatica (Inf)

**Sistemi e Reti Wireless**



Luciano Bononi  
 (bononi@cs.unibo.it)  
 http://www.cs.unibo.it/~bononi/  
 Ricevimento: sempre aperto .  
 Si consiglia di concordare via e-mail almeno un giorno prima  
 (informazioni in tempo reale sulla home page personale)

Figure-credits: some figures have been taken from slides published on the Web, by the following authors (in alphabetical order):  
 J.J. Garcia Luna Aceves (ucsc), James F. Kurose & Keith W. Ross, Jochen Schiller (fub), Nitin Vaidya (uiuc)


© Luciano Bononi 2007
Sistemi e Reti Wireless

**Background on wireless PHY layer**

© Luciano Bononi 2007
Sistemi e Reti Wireless

**RF Properties**


- **Understanding Radio Frequency**
  - Generation, coverage and propagation issues
  - Fundamental for wireless planning and management
- **Radio Frequency Signals**
  - Electromagnetic energy generated by high frequency alternate current (AC) in antennas
  - Antenna: converts the wired current to RF and viceversa



© Luciano Bononi 2007
Sistemi e Reti Wireless

**RF Properties**

- **Amplitude**
  - Higher amplitude RF signals go farther
  - Transmission Power (Watts) = Energy / Time = Joule / Sec
    - More energy (voltage) moves more electrons (current)
    - Power = Voltage \* Current



© Luciano Bononi 2007
Sistemi e Reti Wireless

### RF Properties

- Frequency (and Wavelength)
  - Wireless Spectrum (see next slides)
  - Portion of wireless spectrum regulated by regional authorities and assigned to wireless technologies

Higher Frequencies

Lower Frequencies

1 2 3 ...Time (sec)

Wavelength =  $c / \text{frequency}$

E.g. 2.4 GHz (ISM band)  
Wave Length =  $300.000.000(\text{m/s}) / 2.400.000.000 \text{ Hz} = 0.125 \text{ m} = 12.5 \text{ cm}$

In practice:  
Antennas work better with size =  $1, \frac{1}{2}, \frac{1}{4}$  of wavelength (try to measure antenna size of your IEEE 802.11 device)

© Luciano Bononi 2007      Sistemi e Reti Wireless      5

### RF propagation

- Radio transmission coverage

~4 Ptx

Ptx

Signal detection limit

A d 2d

The range is a function of power transmission (Ptx)  
Signal strength reduces with  $d^k$

In 3D, sphere:  
 $V = (4 \pi r^3 / 3)$   
 $S = (4 \pi r^2)$

© Luciano Bononi 2007      Sistemi e Reti Wireless      6

### Wireless networks' technology

- Radio transmission coverage

Rules of thumb:

- high frequencies are good for short distances and are affected by obstacles
- low frequencies are good for long distances and are less affected by obstacles

obstacles can reflect or absorb waves depending on materials and wave frequencies

© Luciano Bononi 2007      Sistemi e Reti Wireless      7

### RF Properties

- Phase: shift of the wave (in degrees or radians)
  - Positive phase (left-shift), early wavefront
  - Negative phase (right-shift), late wavefront

Example of signal composition with phase variations

Amplitude

Time (phase-degrees)

Sum Main and +180 degrees

Sum Main and +90 degrees

Signal (phase +180 degrees)

Signal (phase +90 degrees)

Main Signal (phase 0 Amplitude)

In practice:  
RF echoes arriving at receivers with different phase may have positive or negative effects... Why?

© Luciano Bononi 2007      Sistemi e Reti Wireless      8

### RF Properties

- Phase: shift of the wave (in degrees or radians)**
  - Positive phase (left-shift), early wavefront
  - Negative phase (right-shift), late wavefront

**In practice:**  
RF echoes arriving at receivers with different phase may have positive or negative effects... Why?

© Luciano Bononi 2007      Sistemi e Reti Wireless      9

### RF Properties

- Phase: shift of the wave (in degrees or radians)**
  - Positive phase (left-shift), early wavefront
  - Negative phase (right-shift), late wavefront

**In practice:**  
RF echoes arriving at receivers with different phase may have positive or negative effects... Why?

© Luciano Bononi 2007      Sistemi e Reti Wireless      10

### RF Properties

- Polarization: (physical orientation of antenna)**
  - RF waves are made by two perpendicular fields:
    - Electric field and Magnetic field

**Horizontal Polarization** (electric field is parallel to ground)

**Vertical Polarization** (electric field is perpendicular to ground)

© Luciano Bononi 2007      Sistemi e Reti Wireless      11

### RF Properties

- Vertical Polarization: typically used in WLANs**

**Intuitively....**

Vertical Polarization (electric field is perpendicular to ground)

© Luciano Bononi 2007      Sistemi e Reti Wireless      12

### RF Properties

**Vertical Polarization: the PCMCIA device problem**

OK Transferred radiation OK  
100% radiation captured

OK Transferred radiation NO  
??% radiation captured

Intuitively...

N.B. the polarization problem is very much important when using distant devices and directional antennas. With short distances signal reflections help!

© Luciano Bononi 2007      Sistemi e Reti Wireless      13

### RF Behaviors

▪ **Radio transmission interference**

© Luciano Bononi 2007      Sistemi e Reti Wireless      14

### Wireless transmission: Electromagnetic waves

▪ **Different parameters of electromagnetic waves:**

- amplitude  $M$  proportional to transmission energy (loudness)
- frequency  $f$  (tone) measured in Hertz (Cycle/sec)
- phase  $\phi$  (peak shift with respect to reference signal) (rad)

Amplitude

same frequency, different amplitude

same frequency, different phase

Phase  $\phi$  ... Time (sec)

Frequency Spectrum

Higher Frequencies

Lower Frequencies

1 2 3 ... Time (sec)

© Luciano Bononi 2007      Sistemi e Reti Wireless      15

### Wireless transmission

▪ **Signal Gain: (measured in Decibels, Db)**

- Increase in amplitude  $M$  proportional to transmission energy
- Active gain (amplifiers)
- Passive gain (antennas focusing signal energy, and additive signal effects)

source

Signal

Amplifier

Amplitude

Additional energy

passive gain: a pitfall vs. regulations?

© Luciano Bononi 2007      Sistemi e Reti Wireless      16

### Wireless transmission

- **Signal Loss: (Db)**
  - Decrease in amplitude **M** proportional to energy waste
    - Intentional (resistance, signal attenuation -> heat)
    - Obstacles, e.g. (walls, water for 2.4 Ghz) and distance (wireless)

source, Signal, reflected energy (return loss), connector, High impedance medium, Amplitude, Wireless propagation loss, A, d

© Luciano Bononi 2007 Sistemi e Reti Wireless 17

### Wireless signal propagation ranges

- **Transmission range**
  - communication possible
  - low error rate
- **Detection range**
  - detection of the signal possible
  - no communication possible
- **Interference range**
  - signal may not be detected
  - signal adds to the background noise

sender, transmission, detection, interference, distance, Ranges depend on receiver's sensitivity!

© Luciano Bononi 2007 Sistemi e Reti Wireless 18

### Wireless Signal propagation effects

- Propagation in free space always like light (straight line)
- Receiving power proportional to  $1/d^2$  ( $d$  = distance between sender and receiver)
- Receiving power additionally influenced by
  - fading (frequency dependent)
  - shadowing
  - reflection at large obstacles
  - refraction depending on the density of a medium
  - scattering at small obstacles
  - diffraction at edges

shadowing, reflection, refraction, scattering, diffraction

© Luciano Bononi 2007 Sistemi e Reti Wireless 19

### Real world example

Raytracing examples, Low signal, high signal

© Luciano Bononi 2007 Sistemi e Reti Wireless 20

### Multipath propagation

- Signal can take many different paths between sender and receiver due to reflection, scattering, diffraction

- Time dispersion: signal is dispersed over time
  - interference with "neighbor" symbols, Inter Symbol Interference (ISI)
- The signal reaches a receiver directly and phase shifted
  - distorted signal depending on the phases of the different parts

© Luciano Bononi 2007      Sistemi e Reti Wireless      21

### Effects of mobility

- Channel characteristics change over time and location
  - signal paths change
  - different delay variations of different signal parts
  - different phases of signal parts

→ quick changes in the power received (short term fading)

- Additional changes in
  - distance to sender
  - obstacles further away

→ slow changes in the average power received (long term fading)

© Luciano Bononi 2007      Sistemi e Reti Wireless      22

### Voltage Standing Wave Ratio (VSWR)

- VSWR occurs with different impedance (Ohm) = resistance to AC current flow between transmitter and antenna
  - VSWR is the cause of "return loss" energy towards the transmitter
  - Measured as ratio between impedance (before and after)
    - E.g. 1,5:1 (impedance ratio before/after is 1,5 times the ideal value)
    - 1 = normalized ideal impedance (1:1 means perfect VSWR)
  - VSWR Causes burnout of transmitter circuits, and unstable output levels

VSWR solution: always use same impedance circuits, cables, connectors (typical 50 Ω in LANs)

© Luciano Bononi 2007      Sistemi e Reti Wireless      23

### Intentional radiator and EIRP

- (Intentional) radiator: (def.) RF device specifically designed to generate and radiate RF signals.
  - ...Includes Tx RF device, cables and connectors (antenna excluded)
  - IR Power output: (subject to regulations) is the power output of last connector just before the antenna
- Equivalent Isotropically Radiated Power (EIRP): the power radiated by the antenna (including the passive antenna gain effect of directional antennas)

EIRP (isotropic antenna): 16mW  
 EIRP (antenna gain +10dBi): 160mW  
 IR Power output: 30-14 = 16mW

© Luciano Bononi 2007      Sistemi e Reti Wireless      24

### System design (under power viewpoint)

- Many factors must be considered in the design of Wireless systems:
  - Power of transmitting device
  - Loss and gain of connectivity devices (cables, connectors, attenuators, amplifiers, splitters) between transmission device and transmitter's antenna
  - Power of the intentional radiator (last connector just before antenna)
  - Power radiated by antenna element (EIRP)
  - Propagation properties of the medium (attenuation before signal reception)
  - Loss and gain of connectivity devices (cables, connectors, attenuators, amplifiers, splitters) between receiver's antenna and receiver device.

© Luciano Bononi 2007      Sistemi e Reti Wireless      25

### Power measurement

- WATT: electric power unit
  - 1 Watt = 1 Ampere \* 1 Volt ( $P=V*I$ ) also  $P= R*I^2$  and  $P = L/t$
  - Current (ampere) is the amount of charge (electrons) flowing as current in a wire
  - Voltage (Volt) is the "pressure" applied to the flow of charge
  - Resistance (impedance) is the obstacle to current flow
  - Power is the energy needed (in a given time unit) to apply a given "pressure" to a given "amount of charge", by resulting in a flow of current.
- Watt and dBm are units used for absolute power measurement
- Typical RF power for WLANs:
  - AP: 30..100 mW (up to 250 mW outdoor), PCMCIA: 15..30 mW

© Luciano Bononi 2007      Sistemi e Reti Wireless      26

### Power measurement

- Decibel (dB): a power measurement unit designed to express power loss
  - It is more practical to use given the logarithmic decay of wireless signals
  - It allows to make easy calculations on "resulting power"
- Decibel (dB) measures the logarithmic relative strength between two signals (mW are a linear absolute measure a energy)
  - $\log_{10}(X) = Y \iff 10^Y = X$

Exponential growth	<ul style="list-style-type: none"> <li><math>1 = 10^0, \log_{10}(1) = 0</math></li> <li><math>10 = 10^1, \log_{10}(10) = 1</math></li> <li><math>100 = 10^2, \log_{10}(100) = 2</math></li> <li><math>1000 = 10^3, \log_{10}(1000) = 3</math></li> </ul>	Linear growth "BEL" units (B)
--------------------	--	-------------------------------

- How strong is a 10 dB signal? (it depends on the reference signal)

© Luciano Bononi 2007      Sistemi e Reti Wireless      27

### Power measurement

- Decibel (dB): 1/10 of a Bel
- E.g. 1000 is one Bel greater than 100 => 1000 is 10 dB greater than 100

Linear signal difference (factor)	<ul style="list-style-type: none"> <li><math>1 = 10^0, \log_{10}(1) = 0</math></li> <li><math>10 = 10^1, \log_{10}(10) = 1</math></li> <li><math>100 = 10^2, \log_{10}(100) = 2</math></li> <li><math>1000 = 10^3, \log_{10}(1000) = 3</math></li> </ul>	<ul style="list-style-type: none"> <li>10 dB</li> <li>10 dB</li> <li>10 dB</li> <li>20 dB</li> <li>20 dB</li> <li>30 dB</li> </ul>
-----------------------------------	--	--

- How strong is a 10 dB signal? (it depends on the reference signal)
  - Positive dB value is power gain, negative dB value is power loss
  - e.g. given 7 mW power, a +10 dB signal gain is 70 mW
  - e.g. given 7 mW power, a -10 dB signal gain (loss) is 0.7 mW
- Power Difference (in dB) between Tx and Rx signal:
  - Power Difference (dB) =  $10 * \log(\text{Power Tx(Watt)} / \text{Power Rx (Watt)})$
- Gain and Loss are relative power measurements: dB is the unit

© Luciano Bononi 2007      Sistemi e Reti Wireless      28

### Power measurement

- Advantage of dB: what is better?
  - E.g.: A signal transmitted at [TX] 100 mW is received at [RX] 0.000005 mW
    - Power Difference (dB) =  $10 \cdot \log([RX] / [TX]) = 10 \cdot \log(0.000005mW/100mW) = -73$
    - A signal transmitted at 100 mW is received with gain (loss) -73 dB
- Advantage of dB: what is better?
  - E.g.: A signal transmitted at 100 mW is received at 0.000005 mW, then it is amplified (\*100) to 0.0005 mW ..... ???
  - A signal transmitted at 100 mW is received with gain (loss) -73+20= -53 dB

-3 dB	½ power in mW (/ 2)
+3 dB	2x power in mW (* 2)
-10 dB	1/10 power in mW (/ 10)
+10 dB	10x power in mW (* 10)

Approximated table (values defined for ease of calculations)

© Luciano Bononi 2007      Sistemi e Reti Wireless      29

### Power measurement

- Practical example:
  - Signal Tx at 100 mW, cable -3dB loss, amplifier +10 dB gain
    - $100 \text{ mW} / 2 (-3\text{dB}) = 50 \text{ mW} \cdot 10 (+10 \text{ dB}) = 500 \text{ mW}$  IR power output
  - Signal TX at 30 mW is received at the antenna as 6 mW (2/10 of TX power)
    - Intentional Radiator Gain (loss) =  $30\text{mW} / 10 = 3\text{mW} \cdot 2 = 6 \text{ mW}$
    - Intentional Radiator Gain (loss) =  $-10 \text{ dB} + 3 \text{ dB} = -7 \text{ dB} (=1/5, 7\text{dB} = 5\text{x})$
- N.B. dBs are additive measures of gain (loss): e.g. 6dB = +3+3 dB, 7dB = 10-3 dB
  - E.g.  $100 \text{ mW} -6 \text{ dB} = 100 \text{ mW} \cdot 3^{-3} = 100 / 27 = 3.7 \text{ mW}$
  - E.g.  $100 \text{ mW} +7 \text{ dB} = 100 \text{ mW} \cdot 10^{+7/10} = 100 \cdot 5 = 500 \text{ mW}$
  - E.g.  $10 \text{ mW} + 5 \text{ dB} = 10 \text{ mW} \cdot 10^{+5/10} = 10 \cdot 3.16 = 31.6 \text{ mW}$
  - E.g.  $10 \text{ mW} + 11 \text{ dB} = ?$
  - E.g.  $50 \text{ mW} - 8 \text{ dB} = ?$

N.B. Approximated values (values defined for ease of calculations)

© Luciano Bononi 2007      Sistemi e Reti Wireless      30

### Power measurement

- dBm: dB-milliWatt, the absolute measure of signal power
  - Assumption: reference signal is 1 mW = 0 dBm(normalization factor)
  - Useful for gain/loss calculation without passing through mW
    - E.g. access point transmits 100 mW =  $1\text{mW} \cdot 10^{+20} = +20 \text{ dBm}$
    - PCMCIA card transmits at 30 mW =  $1\text{mW} \cdot 10^{+4.8} = +4.8 \text{ dBm}$
  - E.g. Tx= 30 mW, cable -2 dB, amplifier +9 dB:
    - $30 \text{ mW} = 1\text{mW} \cdot 10^{+4.8} = 14.7 \text{ dBm}$
    - IR power :  $14.7 \text{ dBm} -2\text{dB} +9\text{dB} = 21.7 \text{ dBm} (147.91 \text{ mW})$
  - In general, for converting mW to dBm and viceversa:
    - $P_{\text{dBm}} = 10 \log(P_{\text{mW}})$     and  $P_{\text{mW}} = 10^{(P_{\text{dBm}} / 10)}$

© Luciano Bononi 2007      Sistemi e Reti Wireless      31

### Power measurement

- mW - dBm: conversion table

-40 dBm	-30 dBm	-20 dBm	-10 dBm	0 dBm	+10 dBm	+20 dBm	+30 dBm	+40 dBm
100 nW	1 µW	10 µW	100 µW	1 mW	10 mW	100 mW	1 W	10 W

-12 dBm	-9 dBm	-6 dBm	-3 dBm	0 dBm	+3 dBm	+6 dBm	+7 dBm	+9 dBm	+12 dBm
62,5 µW	125 µW	200 µW	500 µW	1 mW	2 mW	4 mW	5 mW	8 mW	16 mW

© Luciano Bononi 2007      Sistemi e Reti Wireless      32



### Power measurement

- **dBi: dB-isotropic, the normalized measure of antenna passive gain**
  - Assumption: an isotropic radiator has 100% efficiency in radiating energy in uniform way in every direction (e.g. the Sun)
  - Antennas concentrate energy in non-isotropic way, resulting in **passive gain (space dependent)**. Ideal antenna: zero length dipole

© Luciano Bononi 2007      Sistemi e Reti Wireless      33

### Power measurement

- **dBi: dB-isotropic, the normalized measure of antenna passive gain**
  - If an antenna located in the origin (0,0,0) has twice the radiated energy of an isotropic radiator in a given point (x,y,z), then the antenna gain in (x,y,z) can be defined as +3 dBi. If the energy is 10x the isotropic radiator, the gain is +10 dBi, etc.etc.
  - Q: If the antenna gain is 7 dBi in (x,y,z)?

© Luciano Bononi 2007      Sistemi e Reti Wireless      34

### Power measurement

- **dBi: dB-isotropic, the normalized measure of antenna passive gain**
  - Real antennas always have a preferred direction where the power is greater than isotropic radiator: **gain is always positive in the preferred direction!**
  - Example: 1 mW IR power applied to directional antenna with +10 dBi gain in the preferred direction, would translate in EIRP?
    - $EIRP = 1mW + 10 \text{ dBi} = (10x) = 10 \text{ mW EIRP}$

N.B. this does not mean that antenna generates more power! Antenna concentrates power in preferred direction.

© Luciano Bononi 2007      Sistemi e Reti Wireless      35

### Power measurement

- **dBd: dB-dipole, the normalized antenna passive gain vs. 2.14 dBi half-wave dipole**
  - Reference is a half wave dipole with 2.14 dBi gain in preferred direction!
  - Conversion rule:
    - 0 dBd = 2.14 dBi,       $dBd = (dBi - 2.14)$ ,       $dBi = (dBd + 2.14)$

Reference dipole

© Luciano Bononi 2007      Sistemi e Reti Wireless      36

## Power monitoring (e.g. IEEE 802.11 devices)

- (received) Power monitoring in IEEE 802.11 devices is needed for making device driver to work properly (typical sensitivity range is [-90..+10] dBm):
  - Detect signal (below or above the sensitivity threshold?)
  - Detect signal power (selection of coding technique... That is bitrate!)
  - Detect channel status: idle? Ok, transmit! Busy? Ok, wait.
- Received Signal Strength Indicator (RSSI)
  - Index defined for IEEE 802.11 devices (check device analyzer, if any)
  - RSSI = function (dBm or mW received) = pure number reported to device driver!
  - Unfortunately the RSSI scale is not standard, that is, device dependent!
    - This fact does not allow to compare if device A receives better than device B (assuming different manufacturer) based on RSSI measurement
  - Problem: device A indicates maximum RSSI=255 (8 bits) with -10 dBm signal (0.1 mW), and device B indicates maximum RSSI=32 (5 bits) with -15 dBm (0.03 mW). Q: when both A and B in (x,y,z) receive -15 dBm, which one is better device? That is, which one would you buy if you are a system admin?

© Luciano Bononi 2007

Sistemi e Reti Wireless

37

## Antennas

- Illustration of general issues
  - Convert electrical energy in RF waves (transmission), and RF waves in electrical energy (reception)
  - Size of antenna is related to RF frequency of transmission and reception
  - Shape (structure) of the antenna is related to RF radiation pattern
- Radiation patterns of different antenna types
- Positioning antennas
  - Maximum coverage of workspace
  - Security issues
- Real antenna types: omni-directional, semi-directional, highly-directional


© Luciano Bononi 2007

Sistemi e Reti Wireless

38

## Omnidirectional antenna

- Omn-directional antenna: radiates RF power equally in all directions around the vertical axis.
- Most common example: dipole antenna (see Access Points)
  - See how to make it (disclaimer: do not try this at home):
    - <http://www.nodomainname.co.uk/Omnidirectional/2-4collinear.htm>
    - <http://www.tux.org/~bball/antenna/>
  - Info & fun: <http://www.wlan.org.uk/antenna-page.html>
  - More info: <http://www.hdtvprimer.com/ANTENNAS/types.html>



TV dipole

AP dipole


© Luciano Bononi 2007

Sistemi e Reti Wireless


39

## Omnidirectional antennas: simple dipoles

- Real antennas are not isotropic radiators but, e.g., dipoles
  - shape of antenna proportional to wavelength



- Example: Radiation pattern of a simple Hertzian dipole



- Gain: maximum power in the direction of the main lobe compared to the power of an isotropic radiator (with the same average power)

© Luciano Bononi 2007

Sistemi e Reti Wireless

40

### Omnidirectional antennas: simple dipoles

- Dipole: passive gain is due to concentration (shape) of radiation

Short range, vertical area coverage

Low Gain Dipole

Long range, horizontal area coverage

High Gain Dipole

- Dipole: active gain is obtained with power amplifiers (needs external source of energy)
- N.B. near (below) the dipole the signal is weak! And better radiation is obtained in sub-areas around the dipole!

© Luciano Bononi 2007      Sistemi e Reti Wireless      41

### Omnidirectional antennas: simple dipoles

- Problem: how and when to mount omnidirectional antennas? And which gain is ok?

Low Gain Dipole (e.g. 2 dBi)

Room A

High Gain Dipole (e.g. 8..10 dBi), very flat coverage  
low signal in the proximity of the antenna

Room B

- How: Ceiling? Wall? Client positions? Area? Many factors influence the planning...
- When:
  - need for uniform radio coverage around a central point
  - Outdoor: point-to-multipoint connection (star topology)

© Luciano Bononi 2007      Sistemi e Reti Wireless      42

### Omnidirectional antennas: simple dipoles

- Antenna Tilt: degree of inclination of antenna with respect to perpendicular axis

High Gain Dipole (e.g. 8..10 dBi), very flat coverage mounted on the ceiling

Room A

High Gain Dipole (e.g. 8..10 dBi), very flat coverage mounted on the ceiling with down tilt

Room B

- Some antennas allow a variable degrees downtilt.
- Half signal dispersed "in the sky", 2<sup>nd</sup> half better exploited.

© Luciano Bononi 2007      Sistemi e Reti Wireless      43

### Semi-directional antennas

- Patch (flat antennas mounted on walls)
- Panel (flat antennas mounted on walls)
- Yagi (rod with tines sticking out)

side view (xy-plane) Patch

side view (yz-plane)

top view (xz-plane) Yagi

Horizontal beamwidth

Vertical beamwidth

Semi-directional antenna

Beamwidth cone: -3dB signal boundary off-axis

© Luciano Bononi 2007      Sistemi e Reti Wireless      44

### highly-directional antennas

- Parabolic Dish
- grid

top view (xz-plane) dish

beamwidth

Antenna type	H beamwidth	V beamwidth
Omni-dir.	360°	7°.. 80°
Patch/panel	30° .. 180°	6° .. 90°
Yagi	30° .. 78°	14° .. 64°
Parabolic dish	4° .. 25°	4° .. 21°

Semi-directional antenna

Beamwidth cone:  
-3dB signal boundary off-axis

© Luciano Bononi 2007      Sistemi e Reti Wireless      45

### highly-directional antennas

- Common use: Point-to-point link

Out of beam alignment

beamwidth

beamwidth

beamwidth

Up to 60 km (LOS)

beamwidth

Wind effect: better to have lower gain and wider beam

© Luciano Bononi 2007      Sistemi e Reti Wireless      46

### highly-directional antennas

- Line of sight (LOS):
  - Straight line between transmitter and receiver
  - No obstructions (outdoor long range reduces reflections)
    - Polarization is more important than in indoor scenarios
- Fresnel Zone: RF is not laser light, RF signals diffuse energy in space
  - Ellipse shaped area centered on the LOS axis
  - Most additive RF signal is concentrated in the Fresnel Zone
  - It is important that Fresnel Zone is free from obstacles

Red zone: additive phase signal

Yellow zone: inverse phase signal

© Luciano Bononi 2007      Sistemi e Reti Wireless      47

### highly-directional antennas

- Fresnel Zone (FZ)
  - Blockage of Fresnel Zone causes link disruption
    - Caused by buildings, (growing) trees, foliage, etc.
    - Rule of thumb: < 20% obstruction of Fresnel Zone
    - Practical rule: calculate the radius of FZ leaving 60% unobstructed radius

1st FZ

2nd FZ

Point source

© Luciano Bononi 2007      Sistemi e Reti Wireless      48

$$R_{60\%} = 43.3 \times \sqrt{\frac{d}{4f}}$$


R=radius of 60% central FZ (feet)  
d=distance(Miles), f=freq (GhZ)

$$R_{100\%} = 72.2 \times \sqrt{\frac{d}{4f}}$$

R=radius of 100% FZ (feet)  
d=distance(Miles), f=freq (GhZ)

### highly-directional antennas


- **Fresnel Zone (FZ)**
  - N.B. the FZ radius depends only on the distance  $d$  between antennas, and frequency  $f$  of RF signal!
  - Type of antenna, beam width (degree), and gain (dBi) have no effects!
    - E.g. +13 dBi Yagi (30 degree beam) vs. +24 dBi Dish (5 degrees) have the same FZ!!!!
  - **In practice: if FZ is partially obstructed, it is not useful to use higher gain antennas (with small degree beam) !!!**



© Luciano Bononi 2007      Sistemi e Reti Wireless      49


### highly-directional antennas

- **Fresnel Zone (FZ)**
  - Is not relevant in indoor scenarios (due to reflections...)
- **Consider the Earth bulge!!!**
  - Very long point-to-point connections may have more than 40% FZ obstructed by Earth surface! **Earth Bulge height =  $h$  (feet) =  $D^2/8$**
  - **Minimum antenna height (link > 7 miles)  $H = (43.3 \sqrt{D/4F}) + D^2/8$**



© Luciano Bononi 2007      Sistemi e Reti Wireless      50


### Sectorized-directional antennas

- **Arrays of sectorized directional antennas**

  - top view, 3 sector
  - top view, 6 sector
  - sectorized antenna
- **Space multiplexing (channel reuse)**

© Luciano Bononi 2007      Sistemi e Reti Wireless      51

### Azimuth and Elevation antenna charts


- **Charts for understanding antenna coverage pattern**
  - **Azimuth chart** (pattern seen from front/right/behind/left)
    - Obtained with spectrum analyzer with central antenna frequency
    - Signal measured in dB around the antenna
      - E.g. Dipole pattern: almost circular
      - E.g. yagi pattern: high in front, low beside
  - N.B. distance and Tx power is not relevant (signal strength in a location is relative to every other location in the chart, like with dB)
  - **Elevation chart** (pattern seen front/below/behind/above)



© Luciano Bononi 2007      Sistemi e Reti Wireless      52

## Antennas: diversity

- **Grouping of 2 or more antennas**
  - multi-element antenna arrays
- **Antenna diversity**
  - switched diversity, selection diversity
    - receiver chooses antenna with largest output
  - diversity combining
    - combine output power to produce gain
    - cophasing needed to avoid cancellation (phased antenna array... Requires processor)



© Luciano Bononi 2007

Sistemi e Reti Wireless

53

## Path Loss

- **Path Loss: RF signal "dispersion" (attenuation) as a function of distance**
  - E.g. Possible formulas (36.6 or 32.4)
    - Free space: Loss (in dB) =  $36.6 + (20 \cdot \log_{10}(F)) + (20 \cdot \log_{10}(D))$
    - F (Mhz), D (miles)
- **Link budget issue: 6 dB rule**
  - Each 6 dB increase in EIRP (signal x 4) implies double Tx range (e.g. see table below: 2.4Ghz Path Loss vs distance)

100 meters	- 80.23 dB	-6 dB
200 meters	- 86.25 dB	
500 meters	- 94.21 dB	-6 dB
1000 meters	- 100.23 dB	
2000 meters	- 106.25 dB	-6 dB
5000 meters	- 114.21 dB	
10000 meters	- 120.23 dB	-6 dB

© Luciano Bononi 2007

Sistemi e Reti Wireless

54

## Link Budget Calculation

- **"Link Budget" or "System Operating Margin"**
  - Excess of signal between transmitter and receiver
    - Calculated for outdoor point-to-point connections
  - Measured in dB (relative) or dBm or mW (absolute)
  - Calculation:
    - Receiver sensitivity RS (weakest detectable signal)
      - The lower the better: e.g. IEEE 802.11 card (see device manual), -95 dBm (1Mbps), -93 dBm (2 Mbps), -90 dBm (5.5 Mbps), -87 dBm (11 Mbps)
    - Link Budget: received power (in dBm) - RS (in dBm)
    - E.g. RS = -82 dBm, received power = -50 dBm
      - Link budget =  $-50 - (-82) = +32$  dBm
    - This means the signal has margin of +32 dB before it becomes unviable
- **Fade margin: extra margin for link budget (to cope with multipath variation in indoor/outdoor scenarios): typical [+10..+20] dB**


© Luciano Bononi 2007

Sistemi e Reti Wireless

55

## Link Budget Calculation: example

- **Example: design of transmission system, needs amplifier?**



© Luciano Bononi 2007

Sistemi e Reti Wireless

56